



456 Creamery Way · Exton, PA 19341 · USA

Blow out disc notice

June 2017

Biomarine Inc is notifying all BioPak users of a potential issue with the safety blow out disc of the oxygen cylinder valve.

There has been an increase number of valves that show leaks at the safety blow off disc. This issue appears after performing mandatory 5-year hydrostatic testing. The failure appears to be caused by degradation of the seal washer that seals the burst disc to the valve body.

Biomarine now recommends replacement of the burst disc and washer after completion of the required hydrostatic testing.

Please contact your local distributor or Biomarine directly for information needed to purchase and install replacement burst disc and washer.

Contact Jack Derfler at Jack.derfler@neutronicsinc.com or 484 713-1616.

OR

Lori Baumgard at Lbaumgard@neutronicsinc.com or 484 713-1618